



**BA-2070-03
BIG AIR KIT
KAWASAKI EFI MODELS**

Revision: 1.1 - 02/22/2010

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(2) 1/4" Lock Washers	(2) M6x20mm Cap Screws
(2) Aluminum Filter Spacers	(4) M6x12mm Stainless Cap Screws
(2) 1/4-28 x 1 13/16" Zinc Hex Bolts	(3) 1/4" Rubber Caps
(2) Baron Power Cones	(1) Filter Raincoat
(1) Baron BAK Intake Adapter	(1) Reusable Performance Air Filter
(1) Baron Kawasaki EFI BAK Backing Plate	(1) Chrome BAK Cover

TOOLS REQUIRED:

Factory Service Manual	10mm Open End Wrench
Pliers (std. and needle nose)	10 & 12 mm Sockets
Phillips & Flat Screwdrivers	3, 4, & 5 mm Allen Wrenches

INSTRUCTIONS:

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2019 Barons Custom Accessories