



BA-2070-03
BIG AIR KIT
KAWASAKI EFI MODELS

Page: 1

Revision: 1.1 - 02/22/2010

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

| | |
|---|--|
| (2) 1/4" Lock Washers | (2) M6x20mm Cap Screws |
| (2) Aluminum Filter Spacers | (4) M6x12mm Stainless Cap Screws |
| (2) 1/4-28 x 1 13/16" Zinc Hex Bolts | (3) 1/4" Rubber Caps |
| (2) Baron Power Cones | (1) Filter Raincoat |
| (1) Baron BAK Intake Adapter | (1) Reusable Performance Air Filter |
| (1) Baron Kawasaki EFI BAK Backing Plate | (1) Chrome BAK Cover |

TOOLS REQUIRED:

| | |
|---|--|
| Factory Service Manual | 10mm Open End Wrench |
| Pliers (std. and needle nose) | 10 & 12 mm Sockets |
| Phillips & Flat Screwdrivers | 3, 4, & 5 mm Allen Wrenches |

INSTRUCTIONS:

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2024 Barons Custom Accessories