



BA-3103-00

**SIDE MOUNT LICENSE - Universal Fitment (Mounting bracket required)**

Page: 1

Revision: 1.8 - 02/08/2010

Install Time: 60 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

#### INCLUDED IN THE KIT:

(1) Complete Chrome License Mount w/Cat-Eye Brake Light

#### INSTRUCTIONS:

**NOTE:** This part requires a mounting bracket sold separately

**IMPORTANT:** Please read ALL of the instructions BEFORE beginning the installation.

**NOTES:** Your new Side Mount License comes partially assembled for shipping. Please follow these simple assembly procedures prior to mounting the unit to your motorcycle.

#### ASSEMBLY

1. Remove four (4) license plate frame mount screws and the license plate frame from your new Baron License/Tail Light assembly.

2. Attach backing plate to the mounting bracket with supplied 6x10mm screws

3. Position license plate and install plate frame. Tighten remaining screws.

#### INSTALLATION

1. Wire the tail light into motorcycles wire harness as follows: (Brake light): Taillights red wire to motorcycles brake light wire. (Tail/running light): Taillights yellow wire to motorcycles running light wire. Black wire to ground. You will need approximately 30-inches of wire to properly route taillight wiring up swing arm and into wire harness.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2025 Barons Custom Accessories