



**BA-3103-00**

**SIDE MOUNT LICENSE - Universal Fitment (Mounting bracket required)**

**Page: 1**

**Revision: 1.8 - 02/08/2010**

**Install Time: 60 Minutes**

**CAUTION!** We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

**INCLUDED IN THE KIT:**

**(1) Complete Chrome License Mount w/Cat-Eye Brake Light**

**INSTRUCTIONS:**

**NOTE:** This part requires a mounting bracket sold separately

**IMPORTANT:** Please read **ALL** of the instructions **BEFORE** beginning the installation.

**NOTES:** Your new Side Mount License comes partially assembled for shipping. Please follow these simple assembly procedures prior to mounting the unit to your motorcycle.

**ASSEMBLY**

- 1. Remove four (4) license plate frame mount screws and the license plate frame from your new Baron License/Tail Light assembly.**
- 2. Attach backing plate to the mounting bracket with supplied 6x10mm screws**
- 3. Position license plate and install plate frame. Tighten remaining screws.**

**INSTALLATION**

**1. Wire the tail light into motorcycles wire harness as follows: (Brake light): Taillights red wire to motorcycles brake light wire. (Tail/running light): Taillights yellow wire to motorcycles running light wire. Black wire to ground. You will need approximately 30-inches of wire to properly route taillight wiring up swing arm and into wire harness.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2024 Barons Custom Accessories