



PASSENGER SPORT BOARD & SHORTBOARD MOUNT BRACKETS - Yamaha Road Star 1999 - 2010

Revision: 1.6 - 06/07/2010

Install Time: 15 Minutes

READ INSTRUCTIONS PRIOR TO INSTALLING FLOORBOARDS. WE RECOMMEND THE USE OF BLUE LOCTITE ON ALL THREADED HARDWARE

INCLUDED IN THE KIT:

(2) Floorboard Mount Brackets (BLACK)	(2) 3/8" Lock Washers
(4) M8 x 45mm Chrome Hex Bolts	(4) M8 Chrome Flat Washers
(2) 1/4"-20 x 1/2" Chrome Flathead Allen Screws	(1) 5/32" Long Allen Wrench
(2) 3/8"-16 x 1.0 Hex Cap Bolts	

INSTRUCTIONS:

Your new floorboards come partially assembled for shipping. Please follow these simple assembly procedures prior to mounting the floorboards to your motorcycle.

Assembly

- Fasten the floorboard assembly to the S" shaped mounting bracket (Baron logo facing out) using the supplied 14mm bolt and lock-washer. Do not tighten at this time. (Barons recommends the use of Blue Loctite on this bolt).
- Set fore-aft floorboard angle by installing the supplied Flathead Allen screw in the cam bracket at the desired angle hole. Baron floorboards set to a 15-degree position (middle hole) has been found to be most comfortable and user friendly. Tighten flathead screw. Adjust side tilt angle by moving floorboard stop screw in or out to achieve desired angle.
- Now fully tighten the large 14mm mount bolt. Floorboard is ready for installation. *Installation*
- Remove the two bolts from the left and right stock passenger peg mounting brackets and remove the stock peg assemblies from the bike.
- Install your new Baron floorboards in the same location using the supplied mounting bolts. Insert the mounting bolts (with washer) through the floorboard mounts and fasten then to the bikes frame. It is best to use Blue Loctite when mounting.

Adjustment of floorboard angle after installation

- Slightly loosen the 14mm bolt located on the backside of the mounting bracket the floorboard is attached to.
- Remove the small Allen screw located on visible side of the pivot/cam bracket. Once this screw is removed, adjust the cam to the desired hole and insert and tighten the Allen screw.
- Re-tighten the 14mm bolt. Repeat this process on both sides.

NOTE: It is important to use Blue Loctite on all threaded hardware on the floorboard mounts and pivots/cam

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product. © 2019 Barons Custom Accessories