



BA-7040-00
Passenger Floorboard Brackets
Yamaha, V-Star 950, 1100 & 1300

Page: 1

Revision: 2.6 - 12/07/2009
Install Time: 20 minutes

We recommend the use of Blue Locktite® on all floorboard mounting hardware and that all mounting hardware be retightened after 100 miles.

INCLUDED IN THE KIT:

Left & Right Black Mounting Brackets	(4) M8-1.25 x 45mm Hex Head Bolt Chrome
(2) 3/8-16 x 3/4" SS Flathead Socket Cap	(4) M8-1.25 x 55mm hex Head Bolt Chrome
1/4-20 x 1/2" Flathead Socket Cap	(4) M8 Flat Washers Chrome
5/32" Long Hex/Allen Wrench	

TOOLS REQUIRED:

Allen Wrenches	Blue Locktite®
10 & 12 mm Wrenches	

INSTRUCTIONS:

1. Remove the Baron Sport Boards from their packaging, you will find they come with two chrome Pivot brackets attached. The Pivots are what allows the floorboard to attach to the mounting brackets (Sold Separately) and how the boards tilting can be adjusted.

2. Attach the Pivot to the Floorboard Mounting Bracket using the supplied hardware that comes with the floorboards. Snug the larger bolts up but do not tighten. Take the small 1/4-20x 1/2" Flathead Allen screw and thread them through the small hole/s in the Pivots and into the mounting bracket.

NOTE: You must first select your preferred hole. (The upper hole will place the floorboards in a flat position and the lower hole/s provides an angled mounting position for added comfort and control).

SUGGESTION: The second hole is the most preferred position. Once selected you may now tighten all Flathead hardware.

3. Remove stock pegs/floorboard mounts from your motorcycle.

4. The mounting brackets are left and right side specific. Install Baron mounting brackets in same holes vacated when you removed the stock mounts using the supplied hardware.

NOTE: See specific instructions that may be included with the mounting brackets for specific instructions.

REMEMBER: Use Blue Locktite®

CAUTION: We recommend you re-tighten all mounting bolts after 100 miles.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2025 Barons Custom Accessories