



Revision: 1.0 - 03/15/2010

Please read ALL of the instructions BEFORE beginning the installation.

**INCLUDED IN THE KIT:**

(2) M5 Socket Cap Screws	(4) 5/16-18x3/4 Socket Cap Screws
(4) M5 Set Screws	(2) Longboard Mounts

**INSTRUCTIONS:**

**Unhook spring from underside of stock floorboard.**

**Remove E-clips from stock pivot pins and remove pins. Retain pin, spring, and E-clip as they will be reused.**

**Install new floorboard mounts to frame where stock boards were removed using hardware removed in previous step, and placing end of spring in hole on inside of mount. See Photo #1 on reverse side.**

**Attach new Longboards onto mounts in desired position using supplied M8 cap-head screws. NOTE: not all positions may be usable in all applications.**

**After floorboard mount screws are tightened, tighten set screw on each end of mount to hold M8 floorboard mount screws in place.**

**The M5 cap screw in bottom of mount can be used to adjust tilt angle of the floorboard. Adjust to comfort level desired.**

**Adjust heel shifter so it does not touch floorboard during downshifts. NOTE: heel shifters are removable on most models.**

**Adjust brake pedal for comfort and safety.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2026 Barons Custom Accessories