



Revision: 1.0 - 03/15/2010

INCLUDED IN THE KIT:

(2) 3/8x 3/4 SS Hex Bolts	(2) 3/8x1 1/4" SS Hex Bolts
(2) 3/8 SS Lock Washers	(2) Floorboards
(2) 3/8 SS Washers	

INSTRUCTIONS:

Assembly

Fasten the floorboard assembly to the mounting bracket (Baron logo facing out) using the supplied 3/8x3/4" and lockwasher. Do not tighten at this time. (Barons recommends the use of Blue Loctite on this bolt).

Set floorboard angle by installing the supplied flathead allen screw in the pivot bracket at the desired angle hole. Baron floorboards set to a 15-degree position has been found to be most comfortable and user friendly. Tighten flathead screw. Adjust side tilt angle by moving floorboard stop screw in or out to achieve desired angle.

Now fully tighten the 3/8 bolt. Floorboard is ready for installation.

Installation

Remove the nuts that attach your stock passenger peg mounting brackets to the frame and remove the stock pegs.

Install your new Baron floorboards in the same location using the supplied mounting bolts. Insert the mounting bolts (with washers) through the frame from behind and fasten to your mounting bracket. Be sure you dont over-tighten these bolts. It is best to use Loctite when mounting.

Adjustment of floorboard angle after installation Slightly loosen the 9/16 bolt head located on the backside of the mounting bracket that the floorboard is attached to.

Remove the small allen screw located on visible side of the cam bracket. Once this screw is removed, adjust the cam to the desired hole and insert and tighten the allen screw.

Re-tighten the 9/16 bolt head. Repeat this process on both sides.

<p>Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product. © 2025 Barons Custom Accessories</p>
