



**Revision: 1.0 - 02/23/2010**

**INCLUDED IN THE KIT:**

<b>(4) M5 Set Screws</b>	<b>(2) Longboard Mounts</b>
<b>(4) M8x20 Cap Head Screws</b>	

**INSTRUCTIONS:**

***NOTE: We recommend the use of blue Loctite on all fasteners/mounting hardware.***

**Unhook spring from underside of stock floorboard**

**Remove E-clips from stock pivot pins and remove pins. Retain pin and E-clip, they will be reused. The spring will not be reused.**

**Install new floorboard mounts to frame where stock boards were removed.**

**Mount new Longboards onto mounts in desired position. NOTE: not all positions may be usable in all applications.**

**After screws are tightened, tighten set screw on each end of mount to hold mounting bolt in place.**

**Adjust heel shifter so it does not touch floorboard during downshifts. NOTE: heel shifters are removable on most models.**

**Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2026 Barons Custom Accessories**