



Revision: 1.0 - 02/19/2010

INCLUDED IN THE KIT:

Baron Tach Mount	(2) M5x1.25x18 stainless cap head screws
-------------------------	---

TOOLS REQUIRED:

4mm Allen wrench	
-------------------------	--

INSTRUCTIONS:

Thank you for purchasing the Baron M109 Tach Mount. This part requires the Baron 1-1/2" Xtreme Bar handlebar (BA-7365-00). Installation is reasonably simple providing you follow the instructions below implicitly. As always, please read the instructions in full prior to installing the product. If you feel you dont understand it, please call our tech support line, or have the product installed by a competent technician.

- 1. Remove stock tachometer per service manual instructions.**
- 2. Remove the stock handlebars and risers.**
- 3. Install the Baron Xtreme Bar per instructions included with the handlebar.**
- 4. Using the Baron Tach Mount, sandwich" the mount and the stock tachometer between the risers of the bar. Be sure the tach is visible from the rider position, and youve allowed enough slack in the stock wiring.**
- 5. Tighten the Baron Tach Mount using the provided stainless cap-head screws. Make sure the tach is straight and level.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories