



BA-7401-00
BULLET (ISO) GRIP ENDS

Revision: 2.3 - 02/04/2010
Install Time: 15 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(2) Chromed Billet Bar Ends	
-----------------------------	--

INSTRUCTIONS:

- 1. Remove stock ISO Grip bar end.**
- 2. Install new bar end using stock hardware.**
- 3. We recommend using blue Loctite® on all hardware.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2019 Barons Custom Accessories