



Revision: 1.8 - 04/12/2012

Install Time: 60 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

**INCLUDED IN THE KIT:**

(2) 1/2" to 13mm Studs	(2) 12mm Nylock Nuts
(2) 12mm Washers	(2) 12mm Hex Nuts

**INSTRUCTIONS:**

1. Apply RED Loctite® on the 1/2" section of the supplied studs (this is the one with the course thread).
2. Thread the stud into the bottom of the riser as tight as you can with your fingers. There is no need to use pliers or Vice Grips here!
3. Repeat this procedure on the remaining riser.
4. Slide the riser into the triple tree, and secure with a supplied washer and nylock nut.

**Note:** We strongly recommend the application of Loctite®, or a similar material, on the threads of all bolts.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2024 Barons Custom Accessories