



Revision: 1.0 - 03/16/2010

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(1) 2 pc Clamp	(2) M6x10 Countersunk Screws
(1) Rotor Cover	(4) M6x20 Chrome Hex Screws

INSTRUCTIONS:

NOTE: We recommend the use of Loctite on all fasteners and mounting hardware

Attach new Rotor Cover blade to the upper part of the clamp with supplied countersunk screws using red Loctite.

Place clamp assembly on right side of swing arm and align cover with brake rotor.

Attach lower part of clamp to upper clamp with supplied M6 hex screws and torque to 5 - 6 ft.lbs. Use blue Loctite on these screws.

Check that Rotor Cover does not contact brake rotor while rear wheel is turning.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories