



Revision: 1.0 - 02/23/2010

CAUTION! Read this before installing these products! This part is designed for the Yamaha XVZ1300AT Venture, but will work on other models

INCLUDED IN THE KIT:

(4) M8x65mm Strainless Steel Allen Bolts

(2) Riser Extensions

INSTRUCTIONS:

Note: We strongly recommend the application of Loctite, or a similar material, on the threads of all bolts.

Protect or remove fuel tank.

Remove riser caps from the stock risers.

Rest handlebars on the protected fuel tank.

Place riser extensions onto the stock risers.

Place handlebars onto riser extensions and replace the stock riser caps using supplied M8 x 65mm bolts.

Tighten the upper mount bolts first. Adjust handlebar for comfort, then tighten lower mount bolts to secure the bar.

Check for fuel tank clearance and cable routing prior to riding the motorcycle.

NOTE: This part has been tested to work with stock lines on Yamaha Royal Star Venture models. It has also been tested with a Baron Starbar to work with stock lines. Not for use with Yamaha chrome dash cover, or Yamaha one-piece riser cap.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories