



Revision: 1.0 - 03/16/2010

Please read ALL of the instructions BEFORE installing beginning the installation

**INCLUDED IN THE KIT:**

(1) M6x70 Head Cap Screw

(1) Cover

**INSTRUCTIONS:**

1. Place suitable container under motorcycle and drain coolant from engine.
2. Remove stock cover from bike.
3. Remove Oring from stock cover, It may be reused if it is not damaged or corroded.
4. Place oring in new cover and reinstall with stock screws, Note one shorter screw supplied for upper hole.
5. Refill coolant system with correct mixture of coolant.
6. Start bike and check for leaks.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2019 Barons Custom Accessories