



**Revision: 1.0 - 03/17/2010**

Please read ALL of the instructions BEFORE beginning the installation.

**INCLUDED IN THE KIT:**

(2) M4 Lock Washers	(2) M4x10 Hex Screws
(2) M4 Washers	(1) Mini Teardrop Cover

**INSTRUCTIONS:**

- 1. Remove screws from stock carb cover on left side of bike near the fuel petcock.**
- 2. Using the supplied M4 screws and washers, place a lockwasher and a flatwasher on one of the M4 hex screws (use Blue Loctite or equivalent here).**
- 3. Install this screw with washers into the carb cover holder bracket on left side of bike, coming in from behind the bracket.**
- 4. Hold new teardrop cover up to carb cover holder bracket and reach behind and start screw into the cover (use caution - it is very tight behind this area).**
- 5. Install the other screw/ washer combo (with Loctite) into other hole.**
- 6. Tighten both screws with an end wrench.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2019 Barons Custom Accessories