



Revision: 1.1 - 03/16/2010

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(2) M4 Lock Washers	(1) M5 Flat Washer
(2) M4 Flat Washers	(1) M5 Nut
(2) M4x10 Hex Screws	(1) M6x10 Hex Screw
(2) M6 Chrome Flat Washers	(1) M5x10 Hex Screw
(2) M6x12 Button Head Chrome Screws	(1) Mounting Bracket
(1) M6 Flat Washer	(1) Mini Teardrop Bracket

INSTRUCTIONS:

NOTE: We recommend the use of Blue Loctite on all fasteners and mounting hardware

Warrior Installation

This accessory will cover your throttle bodies when the stock air box has been removed (as with a Baron Stealth Big Air Kit installation).

1. On right side of motorcycle youll find a bronze-colored bracket attached to the top of the throttle bodies. This bracket has one M6 threaded hole and one unthreaded hole in it. This is the attachment point for the new Teardrop Cover mounting bracket. Use the supplied M6x10 hex screw, M5x10 hex screw, M5 & M6 flat washers and M5 nut to secure bracket to throttle bodies.
2. Using supplied M4x10 hex screws and washers, place a lock washer and a flat washer on one of the M4 screws, and install this screw with washers into the cover bracket, coming in from behind the bracket (use blue Loctite or equivalent here).
3. Hold new Teardrop Cover up to bracket and reach behind and start screw into cover (use caution - it is very tight behind this area).
4. Install 2nd M4 screw/washer combo (with Loctite) into other hole.
5. Tighten both screws with an end wrench.
6. Install the two chrome M6x12 screws and washers in the holes left from the removal of stock air cleaner.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2019 Barons Custom Accessories