



Revision: 1.1 - 02/19/2010

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

INCLUDED IN THE KIT:

(1) Mini Teardrop Cover	(2) M4x10 hex screws
(1) Mounting bracket	(2) M4 flat washers
(2) M6x12 button-head chrome screws	(2) M4 lock washers
(2) M6 chrome flat washers	

INSTRUCTIONS:

Please read **ALL** of the instructions **BEFORE** beginning the installation.
We recommend the use of Blue Loctite on all fasteners and mounting hardware.

1. Attach Mini Teardrop Cover to supplied bracket with the M4 screws and washers.
2. Attach mounting bracket to the engine where stock air box was mounted. Use the supplied M6 button-head screws and washers.
3. Re-tighten all screws after 50 miles of riding.

NOTE: This product is intended to be used with a Baron Big Air Kit or other air filter system that removes the air filter box from left side of the engine.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories