



**Revision: 2.6 - 01/02/2013**

**Install Time: 10 Minutes**

**CAUTION!** We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

**INCLUDED IN THE KIT:**

<b>(2) Axle Nut Covers</b>	<b>(4) M6x10 Set Screws</b>
<b>(4) M8-1.25 x 30mm SS Button Head Cap Bolts</b>	

**INSTRUCTIONS:**

- 1. Slide your new Baron Axle Nut Covers into position on the bottom of each front fork leg until seated.**
- 2. Rotate as needed for best coverage. A cut out has been provided for speedometer drive cable clearance on models so equipped.**
- 3. Tighten set screws (2 per Axle Nut Cover) to secure.**
- 4. Honda models require the included M8-1.25 x 30mm bolts to replace stock pinch bolts (2 per fork leg).**

**NOTE:** Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2026 Barons Custom Accessories