



**BA-8540-00**  
**Shorty Side Stand**  
**For Lowered Motorcycles**  
**BA-8520-00/BA-8540-00**  
**Yamaha Road Star/Warrior, V-Star 1100**

Revision: 1.1 - 02/19/2010

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

**INSTRUCTIONS:**

*These shortened side stands are for lowered motorcycles only Installation on a standard-height bike may result in an unstable condition!*

**Road Star/Warrior installation:**

1. Place motorcycle on a suitable stand and ensure it is secure.
2. Remove nut from top of side stand pivot bolt.
3. Remove pivot bolt and spring.
4. Clean and grease pivot area.
5. Install new side stand with stock bolt and supplied special washer. The "flat" of the washer will contact the safety switch when stand is down.
6. Reinstall the spring.

**V-Star 1100 installation:**

1. Place motorcycle on a suitable stand and ensure it is secure.
2. Remove nut from bottom of pivot bolt.
3. Remove the pivot bolt, special washer/spacer and spring.
4. Clean and grease pivot area.
5. Install new side stand with stock bolt, nut and special washer/spacer, in the order they were removed from the stock stand.
6. Remove the long spring hook from stock spring and replace it with supplied hook.
7. Install side stand spring. *Hint: use the stock spring hook and a screwdriver as a spring hook "tool" to reinstall the spring.*

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2026 Barons Custom Accessories