



**Revision: 1.2 - 07/26/2010**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

**INCLUDED IN THE KIT:**

<b>(3) #10 Flat Washer</b>	<b>(1) Dash Extension Yamaha Road Star</b>
<b>(3) 10-24 Machine Hex Nut</b>	

**INSTRUCTIONS:**

Please read **ALL** of the instructions **BEFORE** beginning the installation.

Your new Road Star Dash Extensions are intended to fit under the leading edge of the chromed dash piece, ahead of the fuel tank and next to the bikes frame. There are left and right pieces.

Remove forward mounting screws on either side of the chromed dash (these will also be used to hold dash extension). Apply small amount of masking tape over front and back sides of each extensions upper mounting "tab" and slip the dash extensions tab up under dash until flush with dash edge (circular openings in extensions face frame). Align dash extension for proper fit and appearance, and mark extensions mounting hole location through bolt hole in chrome dash with "Sharpie" or other permanent-type marking pen.

Remove extension and drill 1/4" mounting hole at marked location. Remove masking tape and refit extension to bike using dash mounting bolt. Make any adjustments. Once fit is acceptable, prime and paint extensions as desired. Pass wiring/cables through circular openings in extensions as needed.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2019 Barons Custom Accessories