



**Revision: 1.1 - 02/19/2010**

**INSTRUCTIONS:**

**Hints, tips and precautions on installation and use of Baron Fiberglass Fenders.**

- **Pre-fit all fenders BEFORE you paint them.**
- **Fenders can be trimmed/cut with a cutoff tool or dremel.**
- **Check clearance on lowered rear suspensions with the rear fully collapsed.**
- **Check front fender for corner clearance, forward control clearance, tool bag clearance.**
- **Check rear caliper for clearance (rear caliper can be relocated on some models).**
- **Check tire clearance.**
- **Are you frenching-in lights or license? Check the clearance.**
- **Drill any holes you need for seat mounting, pillion brackets, luggage mounting, light mounting, fender trim, rear racks, license mounting, etc. prior to painting.**
- **Sand gel coat with 320 grit and prime.**
- **Finish sand primer with 400 wet/dry paper and apply base coat.**

**Pre mount fender before you paint!**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2019 Barons Custom Accessories