



Revision: 1.2 - 02/19/2010

Pre-mount fender before you paint!

INSTRUCTIONS:

Hints, tips and precautions on installation and use of Baron Fiberglass Fenders.

- Pre-fit all fenders **BEFORE** you paint them.
- Fenders can be trimmed/cut with a cutoff tool or dremel.
- Check clearance on lowered rear suspensions with the rear fully collapsed.
- Check front fender for corner clearance, forward control clearance, tool bag clearance.
- Check rear caliper for clearance (rear caliper can be relocated on some models).
- Check tire clearance.
- Are you frenching-in lights or license? Check the clearance.
- Drill any holes you need for seat mounting, pillion brackets, luggage mounting, light mounting, fender trim, rear racks, license mounting, etc. prior to painting.
- Sand gel coat with 320 grit and prime.
- Finish sand primer with 400 wet/dry paper and apply base coat.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2024 Barons Custom Accessories