



Revision: 1.2 - 07/26/2010

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

INCLUDED IN THE KIT:

(2) 5/16-24 Jam Hex Nut	(2) #10 Lock Washer
(2) 10/32" x 1-1/4" Hex Head Screw	(1) Side Cover (Left & Right)
(2) #10 Flat Washer	

INSTRUCTIONS:

Please read ALL of the instructions BEFORE beginning the installation.

We recommend the use of blue Loctite on all fasteners and mounting hardware.

1. Remove stock metal side covers per standard shop manual procedures. You will be reusing the two rubber grommets and M6 screw from stock side covers. Install rubber grommets in new Baron left-hand side cover.
2. Install new right-hand side cover onto bike first, securing to frame with stock M6 screw through metal bracket in side cover.
3. Position left-hand side cover on bike, sliding rubber grommets over metal posts on right-side cover.
4. Secure rear of each side cover to frame using supplied hex head screw hidden fasteners. Pass these screws through stock threaded mounting holes in frame from behind and thread them into new side covers. Fasten securely.

NOTE: If your bike is equipped with a set of Baron Braided Stainless Oil Lines, you will need to trim the bottom of right-side cover for clearance around these lines. Test fit cover prior to painting and trim as needed for proper fit.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2019 Barons Custom Accessories