

Install Time: 15 Minutes

LA-7416-01 & LA-7416-01B 1" PULLBACK RISER EXTENSIONS

Page: 1

CAUTION! When installing these extensions be sure you have enough cable slack after installation for fully turning your front end.

INCLUDED IN THE KIT:

(2) 1/2" Lock washers	(2) 1" Extensions
(2) 1/2-13 x 2" Hex Head Bolts	

INSTRUCTIONS:



Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. LA Choppers bears no responsibility on installation costs associated with this product. © 2024 LA Choppers