T.O.R.K. Cover V-Star1100 (all years all models)

Revision: 1.1 - 03/17/2010

INCLUDED IN THE KIT:

(2) M6x20 Chrome Cap Screws	(1) Faux Engine Cover

INSTRUCTIONS:

After installing an oil filter relocation kit, attach this cover to the holes in the right crankcase cover with the supplied M6x20 screws.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2024 Barons Custom Accessories

5221 Oceanus Drive • Huntington Beach, CA 92649 • (657)200-3840 - Ph. • (714)901-0520 - Fax • www.baronscustom.com • tech@baronscustom.com