



Revision: 1.0 - 09/27/2013
Install Time: 10 Minutes

WARNING: This installation requires lifting of the motorcycle. Serious injury can result from an improperly secured motorcycle. Ensure that the motorcycle is securely supported during this procedure.

INCLUDED IN THE KIT:

(2) M10 x 1.25 x 20mm Black Zinc Hex Flange Bolts	(1) Worm Drive Clamp for Heat Shield
(1) Stainless Muffler Clamp	(1) Black Ceramic Heat Shield

INSTRUCTIONS:

INSTALLATION PROCEDURE

- 1. Secure bike on a lift. Unscrew O2 sensor plug from stock exhaust.**
- 2. Remove the 3 bolts from the stock exhaust bracket to the frame (not from the exhaust to the bracket).**
- 3. Loosen the clamp from the stock slip-on muffler and remove the stock slip-on muffler. The stock exhaust gasket will be re-used on your new slip-on.**
- 4. Feed the clamp into the back of the supplied heat shield. Refer to image A. You want to make sure its fed through the same way as shown, otherwise it will be near impossible to tighten after installation.**
- 5. Slide the heat shield w/clamp over the new slip-on muffler. Then slide the supplied muffler clamp over the end of the pipe and install stock exhaust gasket. Refer to image B for clamp orientation.**
- 6. Slide new slip-on over header and line up the bracket to frame mounts.**
- 7. Using the supplied bolts, fasten your new slip-on to the frame.**
- 8. Tighten the clamp that secures the muffler to the header. Rotate and adjust shield for best visible appearance and tighten its worm clamp to secure it in place.**
- 9. Check all bolts and clamps are tight, and installation is complete. Re-tighten bolts after first few rides.**

Image A.



Image B

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2019 Barons Custom Accessories



Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2019 Barons Custom Accessories